



KEYNOTES:

1. CUT THE POLYETHYLENE TUBE TWO FEET LONGER THAN PIPE AND SLIP OVER PIPE AS SHOWN.
2. SPREAD THE POLYETHYLENE TUBE AS SHOWN SO THAT ENOUGH IS LEFT TO PROVIDE A ONE FOOT OVERLAP AT EACH END OF PIPE.
3. TAKE UP SLACK IN THE TUBE ALONG THE PIPE BARREL, MAKING A SNUG BUT NOT TIGHT FIT. FOLD OVER ON TOP OF PIPE AND SECURE IN PLACE WITH 2-LAYERS OF CIRCUMFERENTIALLY OR SPIRAL WRAPPED TAPE ABOUT TWO FEET ON CENTER. (PE SHOWN LOOSE FOR CLARITY) TAPE SHALL BE 10-MIL BLACK ADHESIVE PVC TAPE, CHRISTY'S PIPE WRAP TAPE, OR APPROVED EQUAL.
4. LOWER PIPE INTO TRENCH, BEING SURE THAT THE POLYWRAP IS NOT DAMAGED, AND MAKE UP JOINT.
5. PULL POLYETHYLENE FORWARD FROM PREVIOUS JOINT OVER THE BELL AND SECURE IN PLACE AS SHOWN.
6. PULL POLYETHYLENE FROM NEW PIPE OVER THIS SAME BELL, PROVIDING A DOUBLE LAYER OF POLYETHYLENE AND SECURE IN PLACE AS SHOWN.

Tualatin Valley Water District

1850 SW 170th Ave. Beaverton, OR 97003
(503) 848-3000 www.tvwd.org

DESIGNED: KLS

APPROVED: NWA

SCALE: NONE

PE BAG INSTALL
MODIFIED DIPRA WET
TRENCH METHOD

DATE: 3/1/2018

DETAIL

301